

SECTION II. INSTALLATION

Installation instructions for the PSD are not applicable to this Chapter; however, installation instructions for the hardwired PSD are contained in ASOS Field Modification Kit (FMK) No. 057-1, AAI Systems Management, Inc., February 24, 1994, and for the leased line PSD in ASOS Field Modification Kit (FMK) No. 057-2, AAI Systems Management, Inc., February 24, 1994. Instructions for installation of the memory board associated with the PSD are provided in Chapter 3. The following documents provide technical information on the RTA and ABT (Volume 2 refers to the RTA and Volume 4 to the ABT):

- a. AFOS Handbook 2, Operator's Handbook, Volume 4, Remote Terminals to AFOS (RTA), Auxiliary/Backup Terminal, 3rd Edition, U.S. Department of Commerce, National Oceanic and Atmospheric Administration, July 1989
- b. AFOS Handbook 2, Operator's Handbook, Volume 2, Remote Terminals to AFOS, Part 1 Synchronous Remote Terminals to AFOS, U.S. Department of Commerce, National Oceanic and Atmospheric Administration, July 1986